

Installing Russound USB Drivers for C-Series Controller


Before using SCS-C5 Configuration Software to program a C-Series controller using a USB interface, a USB driver must be downloaded and installed on a PC running Windows XP or above. For PCs running Vista, screen appearances may differ from Windows XP, but it's the same basic procedure.

The following procedure describes how to install the necessary USB drivers on a PC. The USB driver is located in the Russound Document Center and is bundled in the SCS-C5 Zip file.

1. Copy the USB driver file folder onto the PC.
2. Connect the controller to the computer using a USB cable.
3. Power on the controller. The computer will detect the controller as "USB<->Serial" and launch the Found New Hardware Wizard.




4. At the Found New Hardware pop-up select "No, not at this time" when asked if Windows can connect to Windows Update.



5. Click "Next."


6. At the next screen select "Install from list or specific location (Advanced)."



7. Click "Next."

8. At the Search and Installations options screen select "Search for the best driver in these locations", and check only the box for "Include this location in the search:"

9. Click the "Browse" button to point to the location where the Russound USB Driver was saved.




10. Click "Next."


(Continued on back page)

Installing Russound USB Drivers for C-Series (cont'd)

11. Windows will prompt that the software being installed has not passed Windows Logo Testing, click “Continue Anyway”.



12. The “Completing the Found New Hardware Wizard” screen will appear, click “Finish.”



13. Windows will then detect a “USB Serial Port”.



14. Repeat steps 4 - 12 to complete driver install.

15. After the driver has been fully installed a prompt will indicate your new hardware was installed successfully.

