

TS3 Firmware update procedure

Update Steps


1. Power off the TS3 and remove the bezel
2. Insert USB drive with the new firmware image file (*.img, not the ZIP file) into USB slot
3. Power ON the TS3
4. From Main screen, select “Options”
5. From Options screen, select “Screen Setup”
6. From Screen Setup, select “Installer Setup”
7. From Installer Setup, select “Firmware Update”
8. From Firmware Update screen, select “Update My Software”
9. Touchscreen Update screen will appear
   a) Progress bar will appear and track installation
   b) At 100%, user will see “Update Complete”
   c) TS3 will automatically reboot in 5 seconds
10. Remove USB drive from TS3
11. Installation is complete




Step 2



Step 3




Step 4



Step 5



Step 6




Step 7



Step 8

Verify Update

1. To verify firmware, version follow steps 3-6 above
2. From Installers Setup, screen select “About”
3. About screen: Firmware Version should display the updated version





Russound 1 Forbes Road, Newmarket, New Hampshire 03857 USA 603.659.5170 www.russound.com
Technical Support: 8:30 AM ET to 7:00 PM ET 866.888.7466 (toll free in the USA)

©2015 Russound. All rights reserved. All trademarks are the property of their respective owners. Specifications are subject to change without notice. Russound is not responsible for typographical errors or omissions.

06.05.13 WP